

Assembly Instruction



4100021 CABINET JOVE

STEP1




STEP2



STEP3



STEP4



A:2PCS



B:4PCS



C:8PCS



D:2PCS



E: 12PCS



F: 12PCS



G:1PC