





ASSEMBLY INSTRUCTIONS  
5400031& 5400032 WALL LAMP HECTOR



|                                                                                  |          |       |
|----------------------------------------------------------------------------------|----------|-------|
|  | <b>A</b> | 1 PC  |
|  | <b>B</b> | 1 PC  |
|  | <b>C</b> | 2 PCS |
|  | <b>D</b> | 2 PCS |

